

# Vehicle Magnetics Care

## INSTALLATION

The vehicle surface must be clean, dry and waxed prior to applying your magnetic sign. Additionally be sure the brown, magnetic side of the sign is clean and free of debris. The temperature of the magnetic sign must be at least 60° during installation, to be sure it conforms to the shape of the vehicle's surface. The temperature of the vehicle is not a factor. In the desired location, make contact with one edge to the metal surface of the vehicle. From that side, carefully smooth the sign down flat against the steel surface until the entire sign is held magnetically to the vehicle. If the sign is not in the desired position, remove the sign and repeat the above process.

**DO NOT TRY TO STRAIGHTEN THE SIGN BY PULLING ON THE CORNERS AND/OR EDGES. IT MAY STRETCH THE MATERIAL - ESPECIALLY WHEN IT IS HOT!** Make sure the entire sign is in contact with the steel surface of the vehicle - be sure there are no air pockets or bubbles.

***Magnetic signs can not be placed over repairs containing bondo.  
The magnetic will only attach to metal.***

## MAINTENANCE

Remove magnetics by lifting on the center edge, not the corner. This prevents "dog-earing" the corners of the magnetic. Remove the sign from the vehicle at least once a week and wipe dry both the vehicle and sign surfaces. Moisture and debris can collect between the sign and the vehicle if allowed to remain on the vehicle for extended periods of time. This may cause damage to the vehicle or cause the sign to fall off.

To clean the vinyl surface of the magnetic, use a mild detergent in warm water.

## STORAGE

Though the sign you purchased is strong and durable, it can be damaged if it is not taken care of properly. Avoid wrinkling, as any fold will keep it from laying flat against your vehicle. It is preferable to store magnetics on a smooth, flat surface. If you must roll up your sign, do so with the image toward the outside and be sure the roll has an inside diameter of at least 3".